



GRIPPY[®] MAT


Installation and Care Guide

Installation




1. Prepare Floor

Clean and dry your floor thoroughly so Grippy Mat will properly adhere.



2. Cut to Fit

Roll out Grippy Mat and cut it to size using a Safety Knife, scissors or utility blade.



3. Stick It Down!

Position your mat, smooth it out and press it into place using an Installation Board or other tool with a wide, flat edge.

Tools to Make the Job Easier


- **Safety Knife** with recessed blade and protective edges
- **Installation Board** for smoothing mat and guiding cuts



Safety Knife




Installation Board




Angled Corners

For areas with high traffic, cut mat corners at an angle to reduce potential lifting. For best results, use the Installation Board (shown on opposite page) as a cutting guide for perfect 45° angles.



Grouted Floors

To prevent edges from lifting, avoid placing mat edges directly over grout lines. Grippy Mat performs best when all of its edges are in direct contact with clean, smooth surfaces.




Seaming

When “seaming” two mats side-by-side:

1. Install Piece 1 by its leading edge.
2. Install Piece 2 by its side edge, abutting the long side of Piece 1.
3. Make sure your seams are flat, without gaps or overlapping.
4. Smooth Piece 2 away from the middle seam, out toward the edges.


Care & Maintenance



Routine Cleaning


PIG Grippy Mat stays in place and works seamlessly with your current floor cleaning system. You can sweep, mop, vacuum or use a floor scrubber to keep it clean and fresh without the hassles of mats that shift.

NOTE: Do not pull up Grippy Mat to clean the floor underneath until you're ready to replace it.



Floor Scrubbers & Extractors

For Grippy Floor Mat, use your scrubber's low settings and make sure the mat is dry before cleaning. Tougher stains can be pretreated and agitated with a brush to loosen the soil. Trim the mat corners at a 45° angle to help prevent the edges from flipping. When scrubbing is finished, dry-mop any water left behind along the mat's edges. **For Grippy Carpeted Entrance Mat**, a Rug Doctor® or water extractor is recommended to remove captured dirt.



Trimming Edges and Corners

If edges become worn or begin to lift, peel back mat until fresh adhesive is exposed, then trim and press the new edge into place.

Use the Installation Board and Safety Knife shown on page 2 for best results.


..... Watch instructional video: newpig.com/GrippyMatHowToVideo



Handling Excess Water

Excessive rain, snow, ice and slush make it hard to keep floors dry. It's important to remove excess water when your PIG Grippy Mat becomes saturated. Follow these best practices to maximize performance:


1. Use longer runs or wider widths of Grippy Mat to disperse water and limit tracking.
2. Use a wet-vac, Rug Doctor® or extractor to remove excess water.
3. Use fans/blowers to reduce drying times.



Mat Removal

1. Peel up a corner of Grippy Mat using your fingers or the scraper side of the Safety Knife.
2. Bend at the knees while lifting the corner until the mat can be gripped by both hands.
3. Pull the mat up in a smooth, continuous motion, inching backwards as you go.

NOTE: Avoid using jerking motions when removing Grippy Mat.



! Frequency of Changeouts

PIG Grippy Floor Mat is long lasting and extremely durable. If the mat shows obvious signs of wear or a weakened bond to the floor, it should be replaced.

Notice: Even if your mat isn't showing too much wear, it is important to regularly change it out, as the longer the adhesive is down, the harder it can be to pull up.

Questions? Call **1-855-474-7791**

Frequently Asked Questions

Q: Where can I use PIG Grippy Mat?

A: Anywhere you want to stop slips, trips and falls! PIG Grippy Mat replaces rubber-backed mats in entrances, busy walkways and aisles, along grocery produce wet walls, around flower displays, in front of ice machines, freezers, coolers and drinking fountains, in transition areas from stockrooms and production areas to selling floors, offices, and cafeterias — wherever water creates a slipping hazard or dirt and moisture get tracked in.

Q: What types of flooring will Grippy Mat stick to?

A: PIG Grippy Floor Mat will stick to most common commercial floor surfaces, including: concrete, VCT, ceramic and quarry tile, linoleum, and laminate flooring. Grippy Floor Mat is not recommended for wood floors, carpets, or for home or residential use. If you're not sure how PIG Grippy Floor Mat will work for your application, test a 6" x 6" piece in a noncritical area before using.

Q: How can I tell when Grippy Mat needs to be changed?

A: As long as your PIG Grippy Floor Mat shows no sign of obvious wear and maintains a good bond with the floor, you can leave it in place for up to 3 months (Grippy Carpeted Entrance Mat lasts 3–6 months depending on your conditions). It's a good idea to inspect the mat periodically for any signs of excessive wear and to make sure the edges of the mat are maintaining a good bond to the floor. If the edges have lost some adhesion, you can either trim the mat or replace it.

Q: What liquids can PIG Grippy Mat absorb?

A: PIG Grippy Mat is a "universal absorbent mat," which means it absorbs most common liquids and household chemicals, including: water, oils, grease, coolants and more. Certain acids and bases may not absorb well. Please consult our Chemical Compatibility Guide for more info.

Q: How long does it take for PIG Grippy Mat to dry after scrubbing it?

A: PIG Grippy Mat dries quickly but it depends on the conditions at your location, including the amount of water in the mat, overall humidity, and ambient temperature. If you scrub PIG Grippy Mat during routine floor cleaning, it should be completely dry through evaporation within 4–5 hours. You can also use blowers, wet vacs, dry mops, or fans to speed up drying.

Q: How do I remove and dispose of PIG Grippy Mat?

A: The mat should be removed by pulling slowly back on itself at a low angle (45 degrees or less), in a smooth, continuous motion, avoiding jerking pulls. For ease of disposal, the removed mat should be rolled back up into a compact roll. If there are no hazardous substances absorbed inside the mat, it can be disposed of with other common refuse.

Q: Will PIG Grippy Floor Mat damage my floors?


A: Used properly, PIG Grippy Floor Mat should not cause any damage to flooring. However, PIG Grippy Floor Mat may expose preexisting problems by lifting loose or damaged tiles on removal. All adhesive mats have some potential to leave residue or lift or discolor finish coatings and paint depending on the condition and age of the floor surface.

Adhesive notice: If you have questions about the suitability of New Pig adhesive-backed mats for your application, test a 6" x 6" piece in a noncritical area before use. For further assistance, please contact a Floor Safety Specialist at the number below.

Questions? Call 1-855-474-7791




Transition areas



Produce wet walls



Storage & dispensing



Entrances



Lobbies



Coolers & freezers

..... Create safe floors anywhere with PIG Grippy Mat.



New Pig

One Pork Avenue
Tipton, PA 16684-0304

newpig.com

North America: **1-855-474-7791**

Europe: **+31 (0)76 596 92 50**

PIG, PIG logo are registered trademarks in USA and other countries. See tm.newpig.com

UK: **0800 919 900**

Outside North America:

+1-814-684-0101

PIG Grippy Mat is available from New Pig and our fine distribution partners.